



OUTILS "PRESTO"  
TOOLS "PRESTO"  
UTILES "PRESTO"

---




Aiguilles montres bracelets  
Hands for wrist watches  
Agujas para relojes de pulseras

Réveils et instruments  
Alarm-Clocks and instruments  
Despertadores y instrumentos




No 130636/1




No 30669-4

Chaussées et aiguilles m. poches  
Canon pinions + pocket w. hands  
Chaussées + agujas rel. bolsillos

Roues de secondes au centre  
Center second wheels  
Segunderos centrales




No 30637-2




No 30670-6

Roues de petites moyennes + roues  
entraîneuses chronographes (5 bras)  
Third wheels and chrono driv. wheels  
(5 spokes)  
Ruedas sobre la segunda en cronos  
(5 brazos)

Aig. de montres sans toucher  
cadrans  
Watch hands w/o touching dials  
Agujas de relojes sin tocar  
las cadrantes




No 30638-3




No 30671-7

Idem, roues 6 bras  
Idem, wheels 6 spokes  
Idem, ruedas 6 brazos

Couromnes montres + boutons rev.  
Watch crowns + a-clock knobs  
Coronas de relojes + botones desp.



No 4079-3 A



No 4344-9